



1. Pull Pin9 High

6. Connect U15 Pin6 to U17 Pin9 and U15 Pin13 to U8 Pin12

5. Take out U4 and U12. Put them into Memory Board and Put the board at place

2. Change U1 to 65C02, U7 to Enhance //e Rom

4. Disconnect U37 Pin8 and U8 Pin8

3. Remove U31, U33 and U34